



SUBJECT: New quick clamp

CLAMPONTYRE

additional information on use



The special feature of the new ClampOnTyre clamp is that it does not touch the rim, but it grips the tyre by means of three shaped hooks as shown in the figure below.



For a typical installation of the product, the “d” distance between the tyre and the wheel arch should be at least 30 mm.

In the case of **sports, tuned or similar cars**, the “d” distance may be shorter than 30 mm.

Under these conditions, correct mounting is not always ensured. It is recommended to fit the clamp by bringing the upper hook closer to the wheel, tilted slightly upwards.

If clamps cannot be mounted, different gripping type clamps should be used. They are available in the catalogue.

We take this opportunity to remind you that the How-to-Use video for the new ClampOnTyre clamp is available on our website YouTube channel. In the video, you will learn how to use the new clamp correctly as well as how the optional accessories can be used.

You can easily access our YouTube channel by clicking on the following logo  on our Home Page.

After that, you can search for the video you are looking for.

Alternatively, you can watch **ClampOnTyre's** new **How-To-Use** video by clicking [HERE](#)